

UNO4 and UNO8 Zone Expander Connection Instructions

Please visit www.connect2go.com/guides for more information about using these 2 modules with a **Universal** or **Stand-Alone** EVL4 or DUO system or using the UNO8 with an **UNO IP Panel**.

Use the supplied cables and jumpers to set the expanders as required.

